



MediaLink Controller (MLC) - on top of Desk



Silver "pop-up" well beside MLC Controller

- INCLUDES:
- (1) electrical outlet
 - (1) ethernet port for network
 - CABLE for laptop hookup (laying behind pop-up well)

Screen and Light Switches



Problems? Telephone hanging on side of Desk to call Video @5-9136 or IT Helpline @5-9124

- NEW FEATURES:**
- Pull-out tray and affixed shelf for books
 - USB ports on monitor's side - for plugging in your USB key and the Desk's full-size keyboard (if needed)
 - Wireless keyboard (undersized)

1. To turn on video projector (VP) press "ON" button on **MediaLinkController (MLC)**; there will be several seconds delay before VP powers on. Buttons flash fast several seconds. VP takes 90 seconds to full brightness

NOTE: You cannot switch Signal buttons until "ON" button stops flashing

2. While VP is warming up, turn on equipment to be used; firmly pull out keyboard tray

NOTE: SEE instructions attached:

- "Log-In" - To access classroom Network or your personal drive
- "Wireless Mouse" - Includes how to use mouse with Power Point
- "Wireless Keyboard" (undersized)

NOTE: Fullsized keyboard is stored on lower shelf; plugs into USB port/side of monitor

3. Lower screen (automatically stops) and adjust lights, using switches on wall near Desk

4. Display various signals on screen by pressing **Signal** buttons on **MLC Controller**

NOTE: To "hide" computer image until ready to display, press the "PC MUTE" button. (Screen will display "No Signal")

5. Adjust volume by using black "Volume" knob, located under "ON" and "OFF" buttons on **MLC Controller**

NOTE: Only for "110" signal (i.e., cable TV), control volume using "PA System Volume" dial on wall

6. When finished, **LOG OFF computer**, push keyboard and book trays inside Desk, return wireless mouse to cradle, put up screen. **TURN OFF** equipment, especially VP, to preserve lamp. (However, **IF NEXT INSTRUCTOR uses, leave VP on**) To turn off VP, press "OFF" button on **MLC Controller**. Button will flash slowly 2-3 minutes while turning off VP. VP fan will run until lamp is cooled

WARNING !

The **MLC Controller** is programmed to shut off projector if a selection button isn't pushed after 4 hours.

Pushing one of buttons will start the **Controller's** "timer counting" again so no disruption of signal. Or you can push the Display Power Button again to restart the projector.